



## Connection Diagrams

### Emitter of Thru-beam Mode (DC)




#### Connector pin position


##### Euro-style



### PNP output type




### NPN output type




#### Connector pin position

##### Euro-style



### NPN/PNP output type




#### Connector pin position

##### Euro-style




### Emitter of Thru-beam Mode (AC/DC)




#### Connector pin position

##### Micro-style



### Relay output (AC/DC)




#### Connector pin position

##### Micro-style




### SPST Solid-state output (AC/DC)



#### Connector pin position

##### Micro-style



Ag: RP76 SERIES